Uniden
SOUNDS BETTER

Registering a DECT 1802 to a DECT 1811

Your DECT 1802 Additional Handset will need to be registered to your DECT 1811 unit before you can use it. Use these simple instructions to get you up and running.



DECT 1811 **DECT 1802**

Procedure

1 Press and hold the (page) key on the DECT 1811 base unit until it starts to ring (approx. 5 seconds). Release the (page) key.

2 On the DECT 1802 handset, press (menu) and then [5]

3 The available base numbers will be displayed (1, 2, 3, 4), Press [1]

4 When the display shows 4 lines [- - - -], enter [1][5][9][0]

5 The handset will display the base ID number, press (menu) to accept this number.

6 Repeat steps 1 - 5 if you have any additional handsets to register.

This process must be completed within 90 seconds, 3 beeps will indicate that you have exceeded the time. Simply start again from step 1.

Need Help?

Call our HELP line -

Australia - 1300 366 895

New Zealand - 0800 4864 336